



Details:

Ball transfer unit: IP-16

Insert Method: Insert from bottom of puzzle unit  
(as shown in drawing)



Only inserted;  
Use only when a flat surface is available  
under the puzzle unit.